




Stressless® Mary and Mary HR



h = 40.2"
d = 39.0."
sd = 23.2"
sh = 18.1"



You will need 6.3" behind the sofa for the Stressless® reclining function.



Max. Power Recliner Depth: 68.1

1 Seat - Left Arm



Uph: 37.7"
Wood: 37.1"

1 Seat - Center



29.9"

1 Seat - Right Arm



Uph: 37.7"
Wood: 37.1"

Corner




62.4"

Chair



Uph: 45.7"
Wood: 44.1"

2 Seat




Uph: 75.6"
Wood: 74.0"

3 Seat



Uph: 105.5"
Wood: 103.9"

4 Seat



Uph: 135.4"
Wood: 133.9"



Arm Options:



Upholstered



Wood

Available Modules:



Power Left



Power Center



Power Right



NOTES:

- Any Left, Right and Center Modules have the option of Power Recline and/or Adjustable Headrest.
- Arms are not removable.